

## Local Channels 7 and 9 HD Digital Transition

After 12:00 noon on June 12, 2009 all set top boxes and/or TVs must be retuned in order to continue receiving channels 7 and 9. The following are instructions for tuning or adding local Washington, DC channels 7 (ABC) and 9 (CBS) after 12:00 noon on June 12<sup>th</sup> for the KAON set top box model #KACF-S660HD. You will have to follow steps one through eight twice -- once to tune in Channel 7 and a second time to tune Channel 9.

**NOTE:** These instructions are for **set top box users**. If you have a **digital TV**, please perform a channel search; or refer to your TV owner's manual or check the TV manufacturer's website for tuning instructions.

**Instructions:** This procedure assumes that the Set Top Box (STB) you are using is now receiving programming from other Washington, DC locals such as channel 4 (NBC) and 5 (Fox). Click on the link below to find out if you are getting digital local channels: <http://www.capitolconnection.gmu.edu/cable-fags-dtv.htm>

### Step 1

- **POWER** the STB on and wait until the STB has finished "booting" up before starting the programming. This takes less than 60 seconds.

### Step 2

- Press the **MENU** button on the remote and the **SYSTEM SETTING MENU** will display.




### Step 3

- Press the yellow button on the remote control marked **TIMER** once and enter the default **PIN CODE 0000** (four zeros). You should now be in the **MANUAL SEARCH** menu.

### Step 4

- Enter frequency **177.000** for channel 7. After finishing steps 1 – 8, repeat the steps to tune channel 9. Enter frequency **189.000** for channel 9. You can enter only one frequency at a time.

### Step 5

- Use the **ARROW DOWN**  on the remote to highlight **CONST.** (Constellation) and then the **ARROW LEFT** or **RIGHT**  or  to select **8VSB**.



### Step 6

- Press **OK** on the remote control and the STB will now scan for the entered frequency (channel). The scan should take less than 60 seconds.

### Step 7

- Press **OK** to save the channel then press **EXIT** to exit the menu.

### Step 8

- Scroll **CHANNEL UP**  or **DOWN**  to desired channel.

Please note that this procedure has to be repeated for each of the two channels that you are adding.

The Capitol Connection is part of the non-profit George Mason University Instructional Foundation, Inc. Your organization does not pay any program fees to receive the local channels. If you need a service call, there will be a fee. If you have any questions, please contact us at [capcon@gmu.edu](mailto:capcon@gmu.edu). We sincerely appreciate your patronage.

The Capitol Connection  
Customer Service Team  
703-993-3100